

# GREENER'S G.P. GUN INSTRUCTION SHEET

## IMPORTANT

### **Read this BEFORE assembling your G.P. Gun**

Slightly unscrew the coin-slotted barrel locking screw. It is important to ensure that the breech block or the underlever is held down to the FULLEST POSSIBLE EXTENT whilst screwing the barrel home.

The purpose of this is to withdraw the horns of the extractor and save them from being damaged whilst the gun is being assembled.

When assembled the barrel locking screw should be tightened but NOT OVER-TIGHTENED—a turn with a coin is all that is necessary.

The same procedure in reverse should be applied when removing the barrel from the action.

This gun has a full choke barrel unless some other choke boring has been especially ordered by you.

The .729" incorporated in the proof marks does not refer to the degree of choke.

**W. W. GREENER LTD.**

*Makers of Good Guns for Over 125 Years*

*Head Office and Works :*

ST. MARY'S ROW, BIRMINGHAM 4.

*Telegraphic Address :* GREENER, BIRMINGHAM.

*London Showrooms :*

40, PALL MALL, S.W.1.

*Telegraphic Address :* EJECTOR, LONDON.